


AVO

series™




Service Catalogue

AVO Harmony® 140-60

AVO Harmony® 140-60

Exploded View



AVO Harmony® 140-60


Spare Part List*

No	Code	Item	Pcs / product
1	V20-0002	Curtain kit, include bottom plate	1
2a	250-0165	Sideglass, right	1
2b	250-0166	Sideglass, left	1
3	200-0090	Glass mounting bushing	14
4	433-0042-02	Shelf, lower	1
5	433-0043-02	Shelf, middle	1
6	433-0044-02	Shelf, upper	1
7	300-0067	Shelf talker L=527mm	2
8	120-0021	Led lightning	3
9	V20-00	Front grill, complete	1

*The minimum period during which spare parts, necessary for the repair of the appliance is 8 years after placing the last unit of the model on the market.

AVO Harmony® 140-60

Cassette Exploded View



AVO Harmony® 140-60

Cassette Spare Part List*

No	Code	Item	Pcs / product
1	102-0006	Evaporator	1
2	107-0001	Evaporator fan	2
3	107-0006	Condenser fan motor	1
4	110-0003	Connection plug	1
5	120-0017	Led-power SLT15-12VF	1
6	101-0026	Compressor NLE11MN	1
6.1	101-0026-1	Starting relay	1
7	106-0015	Controller Danfoss ERC112C	1
8	103-0012	Condenser	1
9	710-0002	Wheel rotating	4

*The minimum period during which spare parts, necessary for the repair of the appliance is 8 years after placing the last unit of the model on the market.

AVO Harmony® 140-60 Wiring Diagram

